



- KEY:**
- - - Primary make/model paper cutline & template alignment line
  - Sheetmetal trim line
  - Fold line/ inside template alignment line
  - Background data line
  - ✂ Cut paper template
  - ⊕ Drill hole (w/ centerpunch alignment)
  - Alignment hole
  - ↪ Instruction locator

Drill new 3/4" hole for wiring harness outlet

All unshaded holes are for alignment to existing flare fastener holes on body. Cut out the template side. x9

Fender Sheetmetal Trimline  
Once template is aligned on fender, mark the sheetmetal across this solid path, then remove this template and begin cutting, connecting the areas between the existing fastener tabs

Sheetmetal Spacer Holes (x5):  
Drill out these holes FIRST, cutting template before drilling will result in easily folded metal while drilling.

Front

