



Service Bulletin

Subject: Ram HD Highmark Flare Installation Tips

Applicable Models: 2010-2018 Ram HD trucks using AEV Highmark Flares

Recommended Procedure: When installing both front and rear flares on a Ram, it is best to start with the rear. The reason for this is that one of the rear bedside supports is removed and repurposed for use up front. On trucks that are not using flares due to an alternative rear bed, the two bedside support rods will need to be purchased. The Mopar part numbers as of this being written are 68203113AA and 68203112AA, though those may be superseded or changed without notice.

The stick-on templates for the bolt holes are very susceptible to any wax, dust, or grease on the truck, be sure to clean the area VERY thoroughly with a good wax/grease remover prior to placing them.