

## PLEASE READ ENTIRELY BEFORE YOU START

To guarantee a quality installation, we recommend reading these instructions thoroughly before beginning any work. These instructions assume a certain amount of mechanical ability and are not written nor intended for someone not familiar with auto repair.

1. Begin wiring the harness by feeding the orange and blue wired end over the rear hitch and then run it along the side frame. Before pulling the wire through zip-tie the one plug shown below to the wire harness itself.



2. Pull the plug from the previous step into the vehicle, running under the two vehicle harnesses and along the frame. Run the cord behind the shock mount.





3. Run the harness to the other side of the wheel well and be sure to feed the harness over the below fuel lines.



4. Next feed the wire harness above the next vehicle harness that comes after the fuel lines.





5. Run the harness over the frame of the vehicle behind the mounts shown below until you reach the front of the vehicle



6. Feed the harness up to the hood against the fire wall and behind the other harnesses.



7. Finally connect the corresponding wires to the vehicle aux wires according to color.

