

WARN M12000 & M15000 INSTALLATION

Requires AEV M12000 or M15000 Winch Mounting Kit (PN: 10308016)

1. Remove the four screws attaching the winch solenoid cover then remove cover (fig. 1).
2. Remove the two nuts holding the solenoid pack to the mounting plate (fig. 2).
3. Slide the solenoid pack out far enough to access the hold down bolts.
4. Remove the bolts and replace them with the supplied M6 x 15 bolts (fig. 3).
5. Reassemble the solenoid pack.
6. Attach the new solenoid bracket as shown (fig. 4). DO NOT put the washers back on.
7. Install the solenoid bracket to the bumper with the supplied M6 x 20 bolts, nuts, and flat washers (fig. 5).

