



JACK BASE INSTALLATION AND USE GUIDE

INSTALLATION

Your jack base is designed to fit in the rear storage compartment of your JK as shown below. The two oval pockets can be used to store the lug nut extension (AEV p/n P-GOR3434) and wheel lock key.



JACKING INSTRUCTIONS

Your jack base provides the extra height necessary for vehicles equipped with oversize tires. Before using the jack base, refer to your JK Owner's Manual for proper jacking instructions and precautions.

