



REAR SPLASH GUARDS

FOR RAM TRUCKS WITH FACTORY FENDER FLARES

PLEASE READ ENTIRELY BEFORE YOU START

To guarantee a quality installation, we recommend reading these instructions thoroughly before beginning any work. These instructions assume a certain amount of mechanical ability and are not written nor intended for someone not familiar with auto repair.

REQUIRED TOOLS

Automotive Lift or Jack


Common Hand Tools

Drill

1/8", 5/16", and 1/4" Drill Bits



REAR SPLASH GUARDS



ITEM NO.	PartNo	DESCRIPTION	QTY.
1	ARMZ1123AA	SPLASH GUARD, 2019 RAM, 37" REAR LH	1
2	ARMZ1122AA	SPLASH GUARD, 2019 RAM, 37" REAR RH	1
3	ARMZ1126AA	PLATE, RAM, SPLASH GUARD, REFLECTOR	2
4	P-AVO15414	CHRISTMAS TREE FASTENER, 11/16" HEAD DIA., 5/16" STEM DIA., 13/16" LENGTH	4
5	AEV98035AA	WASHER, 1/4"X1" DIA., FENDER	8
6	AEV91055AA	M6 X 1.0 X 20 BUTTON HEAD FLANGED CAP	4
7	AEV93027AA	M6 X 1.0 FLANGE NUT FREE SPINNING	4
8	AEV98044AA	RIVET, 2 PC PUSH IN, 1/8" DIA X 2.312" LONG	6
9	ARMZ1128AA	REFLECTIVE TAPE- ORALITE V98 (RED)	2



II. REAR SPLASH GUARD PREPARATION

1. Fit the plastic reflector backing into place on the Splash Guard. Mark the three holes and drill 1/8" holes through the Splash Guard (fig. 1).




Figure 1

2. Clean and degrease smooth side of the plastic backing then carefully adhere reflective tape.
3. Punch holes through the reflective tape with a utility knife or punch.
4. Reinstall the reflector into place on the splash guard and attach with the supplied plasti rivets.

III. REAR SPASH GUARD INSTALLATION

1. Support the vehicle by the frame until the rear wheels are off the ground.
2. Remove the rear wheels and tires.
3. Remove three factory bolts from the fender flare and SAVE (fig. 2).




Figure 2



4. Drill five 1/4" holes and two 5/16" holes along the bolt pattern in the AEV Rear Splash Guard (fig. 3).




Figure 3

5. Use the three factory bolts removed in step 3 to loosely install the Splash Guard onto the vehicle along the inner holes using factory bolt locations (fig. 4).




Figure 4



- Using the Splash Guard as a template, drill the two innermost holes to 5/16" and outer two holes to 1/4" into the fender flare (fig. 5). NOTE: Be sure Splash Guard is in the proper position and parallel to the ground.




Figure 5

- Install the supplied M6 bolts, nuts, and washers into the 5/16" holes drilled in the previous step.
- Install the supplied fir tree fasteners into the 1/4" outermost holes.